




Caddy®

Arc 151i, Arc 201i



Instruction manual



EU DECLARATION OF CONFORMITY

According to
The Low Voltage Directive 2014/35/EU
The EMC Directive 2014/30/EU
The RoHS Directive 2011/65/EU

Type of equipment

Arc welding power source

Type designation

Arc 151i and Arc 201i from serial number 840 xxx xxxx

optionally used with panels A31 or A33

Arc 151i and Arc 201i are part of the ESAB Caddy product family

Brand name or trademark

ESAB

Manufacturer or his authorised representative established within the EEA Name, address, and telephone No:

ESAB AB

Lindholmsallén 9, Box 8004, SE-402 77 Göteborg, Sweden

Phone: +46 31 50 90 00, www.esab.com

The following harmonised standard in force within the EEA has been used in the design:

EN 60974-1:2012, Arc Welding Equipment - Part 1: Welding power sources

EN 60974-10:2014, Arc Welding Equipment - Part 10: EMC requirements

Restrictive use, Class A equipment, intended for use in locations other than residential.

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within the EEA, that the equipment in question complies with the safety requirements stated above.

Date

Signature

Gothenburg 2019-06-14

A handwritten signature in black ink, appearing to read "Pedro Muniz". The signature is stylized and written over a horizontal line.

Pedro Muniz
Standard Equipment Director

CE 2019

TABLE OF CONTENTS

1	SAFETY	4
1.1	Meaning of symbols	4
1.2	Safety precautions	4
2	INTRODUCTION	7
2.1	Equipment	7
2.2	Control panel	7
3	TECHNICAL DATA	8
4	INSTALLATION	10
4.1	Location	10
4.2	Mains power supply	10
4.2.1	Recommended fuse sizes and minimum cable area	10
5	OPERATION	11
5.1	PFC - Power factor correction	11
5.2	Connections and control devices	11
5.3	Connection of welding and return cable	12
5.4	Overheating protection	12
5.5	MMA welding	12
5.6	TIG welding	13
5.7	Remote control unit	14
6	MAINTENANCE	15
6.1	Inspection and cleaning	15
7	TROUBLESHOOTING	16
7.1	Fault codes	16
8	ORDERING SPARE PARTS	17
	DIAGRAM	18
	ORDERING NUMBERS	22
	ACCESSORIES	23

1 SAFETY

1.1 Meaning of symbols

As used throughout this manual: Means Attention! Be Alert!

**DANGER!**

Means immediate hazards which, if not avoided, will result in immediate, serious personal injury or loss of life.

**WARNING!**

Means potential hazards which could result in personal injury or loss of life.

**CAUTION!**

Means hazards which could result in minor personal injury.

**WARNING!**

Before use, read and understand the instruction manual and follow all labels, employer's safety practices and Safety Data Sheets (SDSs).



1.2 Safety precautions

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
 - its operation
 - location of emergency stops
 - its function
 - relevant safety precautions
 - welding and cutting or other applicable operation of the equipment
2. The operator must ensure that:
 - no unauthorised person is stationed within the working area of the equipment when it is started up
 - no-one is unprotected when the arc is struck or work is started with the equipment
3. The workplace must:
 - be suitable for the purpose
 - be free from drafts

4. Personal safety equipment:
 - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves
 - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns
5. General precautions:
 - Make sure the return cable is connected securely
 - Work on high voltage equipment **may only be carried out by a qualified electrician**
 - Appropriate fire extinguishing equipment must be clearly marked and close at hand
 - Lubrication and maintenance must **not** be carried out on the equipment during operation

**WARNING!**

Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting.

**ELECTRIC SHOCK - Can kill**

- Install and ground the unit in accordance with instruction manual.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from work and ground.
- Ensure your working position is safe

**ELECTRIC AND MAGNETIC FIELDS - Can be dangerous to health**

- Welders having pacemakers should consult their physician before welding. EMF may interfere with some pacemakers.
- Exposure to EMF may have other health effects which are unknown.
- Welders should use the following procedures to minimize exposure to EMF:
 - Route the electrode and work cables together on the same side of your body. Secure them with tape when possible. Do not place your body between the torch and work cables. Never coil the torch or work cable around your body. Keep welding power source and cables as far away from your body as possible.
 - Connect the work cable to the workpiece as close as possible to the area being welded.

**FUMES AND GASES - Can be dangerous to health**

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

**ARC RAYS - Can injure eyes and burn skin**

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

**NOISE - Excessive noise can damage hearing**

Protect your ears. Use earmuffs or other hearing protection.

MOVING PARTS - Can cause injuries



- Keep all doors, panels and covers closed and securely in place. Have only qualified people remove covers for maintenance and troubleshooting as necessary. Reinstall panels or covers and close doors when service is finished and before starting engine.



- Stop engine before installing or connecting unit.
- Keep hands, hair, loose clothing and tools away from moving parts.

FIRE HAZARD



- Sparks (spatter) can cause fire. Make sure that there are no inflammable materials nearby.
- Do not use on closed containers.

MALFUNCTION - Call for expert assistance in the event of malfunction.

PROTECT YOURSELF AND OTHERS!



CAUTION!

This product is solely intended for arc welding.




WARNING!

Do not use the power source for thawing frozen pipes.



CAUTION!

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.




NOTE!

Dispose of electronic equipment at the recycling facility!

In observance of European Directive 2012/19/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.



ESAB has an assortment of welding accessories and personal protection equipment for purchase. For ordering information contact your local ESAB dealer or visit us on our website.

2 INTRODUCTION

Arc 151i, Arc 201i is a welding current power source intended for use with coated electrodes (MMA welding) and TIG welding.

ESAB accessories for the product can be found in the "ACCESSORIES" chapter of this manual.

2.1 Equipment


Arc 151i, Arc 201i is supplied with a 3 m welding cable, return cable, 3 m mains cable and an instruction manual for power source and control panel.

Instruction manuals in other languages can be downloaded from the website, www.esab.com.

2.2 Control panel

Control panel A31

- Knob for setting the current
- Mains voltage LED (green)
- Thermal overload trip indicator (yellow)



Control panel A33



Welding process parameters are controlled via the control panel.



NOTE!

See the separate instruction manual for a detailed description of the control panel.

3 TECHNICAL DATA

	Arc 151i	Arc 201i
Mains voltage	230 V, 1 ~ 50/60 Hz	230 V, 1 ~ 50/60 Hz
Primary current:		
I_{\max} TIG	13.8 A	24.1 A
I_{\max} MMA	21.3 A	24.9 A
No-load power	30 W	32 W
Voltage/current range, MMA:		
A31	8 A / 20 V - 150 A / 26 V	-
A33	4 A / 20 V - 150 A / 26 V	4 A / 20 V - 170 A / 26.8 V
Voltage/current range TIG	3 A / 10 V - 150 A / 16 V	3 A / 10 V - 220 A / 18 V
Permissible load at MMA:		
25% duty cycle	150 A / 26.0 V	170 A / 26.8 V
60% duty cycle	100 A / 24.0 V	130 A / 25.2 V
100% duty cycle	90 A / 23.6 V	110 A / 24.4 V
Permissible load at TIG:		
20% duty cycle	-	220 A / 18.8 V
25% duty cycle	150 A / 16.0 V	-
60% duty cycle	120 A / 14.8 V	150 A / 16.0 V
100% duty cycle	110 A / 14.4 V	110 A / 14.4 V
Power factor at maximum current	0.99	0.99
Efficiency at maximum current	80%	81%
Open-circuit voltage:		
A31 without VRD function ¹⁾	58 - 72 V	-
A33 VRD function deactivated ²⁾	56 V	56 V
VRD function activated ²⁾	23 V	22 V
Operating temperature	-10 °C - +40 °C	-10 °C - +40 °C
Transportation temperature	-20 °C - +55 °C	-20 °C - +55 °C
Constant A-weighted sound pressure	< 70 dB	< 70 dB
Dimensions (l × b × h)	418 × 188 × 208 mm	418 × 188 × 208 mm
Weight:		
with A31	7.9 kg	-
with A33	8.1 kg	8.3 kg
Enclosure class	IP 23	IP 23
Application class	S	S

1) Valid for power sources without VRD specification on the rating plate.

2) Valid for power sources with VRD specification on the rating plate. The VRD function is explained in the instruction manual for the control panel.

Mains supply, Z_{\max}

Maximum permissible line impedance of the network in accordance with IEC 61000-3-11.

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40 °C / 104 °F, or below.

Enclosure class

The **IP** code indicates the enclosure class, i.e. the degree of protection against penetration by solid objects or water.

Equipment marked **IP23** is intended for indoor and outdoor use.

Application class

The symbol **S** indicates that the power source is designed for use in areas with increased electrical hazard.

4 INSTALLATION

The installation must be carried out by a professional.



NOTE!

Mains supply requirements

This equipment complies with IEC 61000-3-12 provided that the short-circuit power is greater than or equal to S_{scmin} at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power greater than or equal to S_{scmin} . Refer to the technical data in the TECHNICAL DATA chapter.


4.1 Location

Position the power source such that its cooling air inlets and outlets are not obstructed.

4.2 Mains power supply

Check that the welding power source is connected to the correct voltage and that the correct fuse size is used. A protective earth connection must be made in accordance with regulations.

Location of rating plate



4.2.1 Recommended fuse sizes and minimum cable area

	Arc 151i	Arc 201i
Mains voltage	230 V \pm 10 %, 1-phase	230 V \pm 10 %, 1-phase
Mains frequency	50-60 Hz	50-60 Hz
Mains cable, area	3G2.5 mm ²	3G2.5 mm ²
Phase current I_{1eff}	11 A	14 A
Welding cable, area	16 mm ²	16 mm ²
Fuse:		
anti-surge	16 A	16 A
type C MCB	16 A	16 A




NOTE!

The mains cable areas and fuse sizes as shown above are in accordance with Swedish regulations. For other regions, supply cables must be suitable for the application and meet local and national regulations.

5 OPERATION

General safety regulations for handling the equipment can be found in the "SAFETY" chapter of this manual. Read it through before you start using the equipment!




5.1 PFC - Power factor correction

The Caddy Arc 151i/201i are 230 V single-phase power sources equipped with a PFC circuit making it possible to use the full range of the power source on a 16 A fuse.

The PFC also protects the power sources against fluctuating mains voltage and makes it safer to use with a generator. Caddy Arc 151i/201i can operate with extra long mains cables, over 100 m, giving you a very larger working radius.

5.2 Connections and control devices

- | | |
|---|--|
| 1 Connection (+)
MMA: for return cable or welding cable
TIG: for return cable | 4 Connection (+)
MMA: for return cable or welding cable
TIG: for Tig torch I |
| 2 Connection for remote control unit | 5 Toggle switch for mains power supply 0 / 1 |
| 3 Control panel | 6 Mains cable |



5.3 Connection of welding and return cable

The power source has two outputs, a positive terminal (+) and a negative terminal (-), for connecting welding and return cables. The output to which the welding cable is connected depends on the type of electrode used. The connecting polarity is stated on the electrode packaging. Connect the welding cable to the terminal stated on the electrode packaging.

Connect the return cable to the other output on the power source. Secure the return cable's contact clamp to the work piece and ensure that there is good contact between the work piece and the output for the return cable on the power source.

5.4 Overheating protection

The welding power source has a thermal overload trip which operates if the temperature becomes too high, interrupting the welding current and lighting a yellow indicating lamp on the front of the power source. The thermal overload trip resets automatically when the temperature has fallen.

5.5 MMA welding

Arc 151i / 201i gives direct current, and you can weld most metals to alloy and non- alloy steel, stainless steel and cast iron.

Arc 151i / 201i allows you to weld most coated electrodes from Ø 1.6 mm to Ø 3.25 mm.


MMA welding may also be referred to as welding with coated electrodes. Striking the arc melts the electrode, and its coating forms protective slag.

If, when striking arc, the tip of the electrode is pressed against the metal, it immediately melts and sticks to the metal, rendering continued welding impossible.

Therefore, the arc has to be struck in the same way that you would light a match.


Quickly strike the electrode against the metal, then raise it so as to give an appropriate arc length (approx. 2 mm). If the arc is too long, it will crackle and spit before finally going out completely.

If you are working on a welding bench, check before attempting to strike the arc that residual waste metal, pieces of electrode or other objects on the bench do not insulate the part to be welded.



Once the arc has been struck, move the electrode from left to right. The electrode must be at an angle of 60° to the metal in relation to the direction of welding.

When you want to weld wide beads, or when you want the weld to be so thick that you have to weld in a number of layers, however, you have to use lateral movements.



5.6 TIG welding

TIG welding melts the metal of the workpiece, using an arc struck from a tungsten electrode, which does not itself melt. The weld pool and the electrode are protected by shielding gas.


TIG welding is particularly useful where high quality is demanded and for welding thin plate. Arc 151i / 201i also has good characteristics for TIG welding.

In order to TIG weld Arc 151i / 201i must be equipped with:

- a TIG torch with gas valve
- a welding gas cylinder (a suitable welding gas)
- a welding gas regulator (suitable gas regulator)
- tungsten electrode
- suitable auxiliary material, if necessary.



TIG scrape start (only A31)

To scrape start lightly scrape the tungsten electrode against the workpiece to create an arc.



"Live TIG-start" (only A33)

With "Live TIG start" the arc strikes when the tungsten electrode is brought into contact with the workpiece and then lifted away from it.



5.7 Remote control unit

The remote control unit is connected to the remote control socket on the power source.

6 MAINTENANCE



NOTE!

Regular maintenance is important for safe and reliable operation.

Only those persons who have appropriate electrical knowledge (authorised personnel) may remove the safety plates to connect or carry out service, maintenance or repair work on welding equipment.



CAUTION!

All warranty undertakings from the supplier cease to apply if the customer attempts any work to rectify any faults in the product during the warranty period.

6.1 Inspection and cleaning

Power source

Check regularly that the welding power source is not clogged with dirt.

How often and which cleaning methods apply depend on: the welding process, arc times, positioning of power source, and the surrounding environment. It is normally sufficient to blow down the power source with dry compressed air (reduced pressure) once a year.

Clogged or blocked air inlets and outlets otherwise result in overheating.

TIG torch

The TIG torch's wear parts should be cleaned and replaced at regular intervals in order to achieve trouble-free welding.

7 TROUBLESHOOTING

Try these recommended checks and inspections before sending for an authorized service technician.

Type of fault	Corrective actions
No arc.	<ul style="list-style-type: none"> • Check that the mains power supply switch is turned on. • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check to see whether the MCB has tripped.
The welding current is interrupted during welding.	<ul style="list-style-type: none"> • Check whether the thermal protections have tripped (indicated by the orange lamp on the front panel). • Check the mains power supply fuses.
The thermal protection trips frequently.	<ul style="list-style-type: none"> • Check to see whether the dust filter is clogged. • Make sure that you are not exceeding the rated data for the power source (i.e. that the unit is not being overloaded).
Poor welding performance.	<ul style="list-style-type: none"> • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check that the correct electrodes are being used. • Check the gas flow.

7.1 Fault codes

Arc 151i, 201i comes with built-in fault monitoring. If a fault occurs, a code is shown in the display. See instruction manual for the control panel.

8 ORDERING SPARE PARTS



CAUTION!


Repair and electrical work should be performed by an authorised ESAB service technician. Use only ESAB original spare and wear parts.

Arc 151i and Arc 201i are designed and tested in accordance with the international and European standards **IEC-/EN 60974-1** and **IEC-/EN 60974-10**. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the mentioned standard.


Spare parts and wear parts can be ordered through your nearest ESAB dealer, see esab.com. When ordering, please state product type, serial number, designation and spare part number in accordance with the spare parts list. This facilitates dispatch and ensures correct delivery.

DIAGRAM


Arc 151i




DIAGRAM




Arc 201i












ORDERING NUMBERS






Ordering no.	Denomination	Type
0460 445 881	Welding Power source	Caddy® Arc 151i, A31
0460 445 883	Welding Power source	Caddy® Arc 151i, A33
0460 445 884	Welding Power source	Caddy® Arc 201i, A33
0460 449 174	Instruction manual Control panel	A32, A33, A34
0459 839 027	Spare parts list	Arc 151i, Arc 152i, A31
0459 839 028	Spare parts list	Arc 151i, Arc 201i, A33

Instruction manuals and the spare parts list are available on the Internet at: www.esab.com

ACCESSORIES

0460 265 001	Strap	
0460 265 002	Cable holder 2 pcs	
0460 265 003	Shoulder strap	
0459 366 885	Trolley for 5-10 litre gasbottle	
0700 006 898 0700 006 899	Welding cable kit, Arc 151i Return cable kit, Arc 151i	
0700 006 900 0700 006 901	Welding cable kit, Arc 201i Return cable kit, Arc 201i	
0700 300 539 0700 300 553	Tig torch TXH 151V, Arc 151i Tig torch TXH 201V, Arc 201i	
0349 501 024	Remote control MMA 1 (10 m cable) MMA and TIG: current	
0349 090 886	Foot control FS002 MMA and TIG current	

ACCESSORIES

0459 491 896	Remote control unit AT1 MMA and TIG: current	
0459 491 897	Remote control unit AT1 CF MMA and TIG: rough and fine setting of current.	
0459 552 880	Remote cable 12 pole - 8 pole 5 m	
0459 552 881	10 m	
0459 552 882	15 m	
0459 552 883	25 m	



A WORLD OF PRODUCTS AND SOLUTIONS.



For contact information visit esab.com

ESAB AB, Lindholmsallén 9, Box 8004, 402 77 Gothenburg, Sweden, Phone +46 (0) 31 50 90 00

<http://manuals.esab.com>

