

D0601/D0701 Hold Open Arm Strength Adjustment:

1. Adjust Hold Open angle by removing Nut A and adjusting the gear to the required angle.
2. Remove Arm B by unscrewing Nut B from the link arm.
3. Use a flat screw driver to turn the screw in the link arm to clockwise or anti-clockwise to adjust the strength of the hold open.
4. Reassemble arm again ensuring all parts are in the correct position.

