



# Installation Instructions:

## Parallel Fixing




Please install the closer body and parallel arm bracket according to the template

1




Dismount the main arm and link arm

2




Fix link arm, parallel arm bracket and closer body by M5 screws

3



Rotate the pinion approximately at 100° by wrench as illustrated and then assemble the main arm with pinion by M6 screw tightly




4



Connect the main arm and link arm as illustrated


5

## Speed Adjustable




# Installation Instructions:

## Parallel Fixing




Please install the closer body and parallel arm bracket according to the template

1




Dismount the main arm and link arm

2




Fix link arm, parallel arm bracket and closer body by M5 screws

3



Rotate the pinion approximately at 100° by wrench as illustrated and then assemble the main arm with pinion by M6 screw tightly


4



Connect the main arm and link arm as illustrated

5

## Speed Adjustable



Fast Slow

