Quick Installation Guide

Cloud Easy Smart Outdoor PoE Switch

WI-PCES206-O | WI-PCES210G-O

www.wireless-tek.com

1.Packing Content

Switch x 1

Quick Installation Guide x 1

Power Cord x 1

Rubber Plug x 2

M36 Waterproof Gland x 2
(Optional)

Metal Tie Accessory x 2

2. Appearance Overview

For WI-PCES206-O

• Front Panel



• LED Indicator and Button

LED Indicator&Button	Description
Extend	The transmission distance of PoE Port can be up to 250m with 10Mbps
VLAN	Enable Port VLAN, each PoE port just can send data to uplink port.
PD Alive	All PoE ports enable PoE watchdog function, which can detect and reboot the offline compliant PoE powered devices.

LED Indicator&Button	Description
PWR	On: The switch is powered on Off: The switch is powered off or power supply is abnormal
PoE	On: PoE enabled Off: PoE disabled
Link	On: Port connected Off: Port disconnected Blinking: Data transmission
Reset	Hold for 10 sec. to restore factory default

For WI-PCES210G-O

• Front panel

• LED Indicator and Button

LED Indicator&Button	Description
Extend	The transmission distance of PoE Port can be up to 250m with 10Mbps
VLAN	Enable Port VLAN, each PoE port just can send data to uplink port.
PD Alive	All PoE ports enable PoE watchdog function, which can detect and reboot the offline compliant PoE powered devices.

LED Indicator&Button	Description
PWR	On: The switch is powered on Off: The switch is powered off or power supply is abnormal
PoE	On: PoE enabled Off: PoE disabled
Link	On: Port connected Off: Port disconnected Blinking: Data transmission
Reset	Hold for 10 sec. to restore factory default

3.Device Installation

• **Connection**

• 1.Route the power cable and network cable through the sealing sleeve.



• 2.Loosen the screws on the left side of the switch with a screwdriver.

• 3.Slide down the front lower cover to open.



• 4.Screw the sealing sleeve to the round hole at the bottom of the switch and tighten it. Connect the power cable and network cables to the ports.

• 5.Close the cover and tighten the screws.

• 6.Check whether the installation is secure.

Note: It is recommended that the device be well grounded.

4.Installation

• Pole-mount



• Wall-mount

5.Management

• **Log in to the switch locally**

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.

The Switch is set to DHCP by default, so it will try to obtain an IP address automatically. If that fails, then it will use the default fallback **IP address, 192.168.0.1**.

To log in, follow these steps:

1.Launch your web browser. Type the appropriate IP address in the address field.

2.The login screen will appear. In the factory state, the first login requires setting an account and password.



• **Cloud login switch configuration**

1. Log in to the cloud management page

(No account, you need to register an account to log in. The URL is http://cloud2.wireless-tek.com)



2.Enter the cloud binding switch

①Expain:The switch must be connected to the internet to bind successfully.

Please enter the device serial number to bind a device to the current group, device can be off when binding.

②Explain: The 11-digit SN code of the switch is shown on the sticker on the back of the switch as shown in the figure below)

3.After binding, you can use the Switch in the Tunnel option in the cloud management, and then use EWEB to enter the switch.

(Explain:The Cloud Easy Smart Outdoor PoE Switch is linked with the other type of Wi-Tek cloud management devices, such as cloud L2, L3 management switch, gateway, wireless AP, etc.)

Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within the warranty period, we will provide professional maintenance service.
- Please keep this card and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, stolen damaged, warranty card loss will disqualify the product from limited warranty.

Wireless-Tek Technology Limited

Address: Building D, Units 1801~1807, 1812, Huaqiang Era Plaza, Tangwei Community, Fuhai Street, Bao'an District, Shenzhen City, Guangdong Province, China.

Website: www.wireless-tek.com

Tel: 86-0755-3251 1299

Email: sales@wireless-tek.com

Technical Support: tech@wireless-tek.com

CE FC UK RoHS