



AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

FITTING INSTRUCTIONS FIT1266

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

SIDE CAB EXTENDERS **Fuso HD/Heavy/Shogun long guard**

SK117T

MADE IN NEW ZEALAND

1. Remove air filter RH side of cab
2. Remove the rear two roof bolts on each side
3. Fit the SK117T sides to the roof mount holes using M8 x 40mm bolt, spring washer and penny washers. Finger tight only.



4. Remove the nuts holding the top air-filter mount.
Remove the lower air-filter support bracket



5. Fit the upper supplied bracket using original nuts to the upper air filter mount

6. Refit the lower air filter bracket through the holes in the RH SK117T rear flange using the supplied M8 x 30mm bolts



7. Loosely fit the bracket to the opposite LH side to support the LH SK117T rear flange. Use M8 x 30mm



8. Remove the factory bolt that holds the mud guard to the rear of the truck both sides.
9. Use the supplied M8 x 50mm, washers and spacer tube to fasten the lower SK117T to the factory mudguard/body hole.



10. Install the lower guard internal support bracket.
Align the internal support bracket as per image. Fasten with the two self tapping screws to the inside of the mudguard.



11. While aligning the outside of the SK117T with the mudguard, drill an 8mm hole through the guard and SK117T side cab extension. Fasten with M8 x 30mm bolt and washers.



12. Check all bolts are firmly fastened.
13. Replace air filter