



AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

FITTING INSTRUCTIONS FIT1309


PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

BONNET GUARD VW AMAROK 2024+ BRAZIL / ARGENTINA ONLY


BG676D

MADE IN NEW ZEALAND

1. Clean and open bonnet.
2. Trial fit the Bonnet Guard and note the holes corresponding with the holes in the underside of bonnet.
3. Note sequence as per diagram as below. Fit Bonnet Guard in position and fasten securely with supplied screw making sure the bonnet guard is between the rubber strip and bonnet.



4. Apply the anti-abrasive tape on edge of hood where plastic fastening W-clip secures the Bonnet Guard near the fenders. Use the supplied alcohol prep-pads to cleanse the area first.
5. Snap the supplied plastic W-clip into hole position on Bonnet Guard as shown, over the anti-abrasive tape.



Wash acrylic with a mild soap and lukewarm water solution, using a clean, soft cloth or sponge.

**CLOSE THE BONNET BY DROPPING FROM 6" HEIGHT.
ASSIST CLOSURE ONLY BY PRESSING ON THE BONNET.
NEVER PRESS ON THE BONNET GUARD**