



HARDLIDS & ACCESSORIES

**RAD HARDLID - TRITON 2023+
STANDARD - FITTING INSTRUCTION**



HARDLIDS & ACCESSORIES

Vehicle bodies and vehicle installation can vary, so please read the following instructions as they refer to important information which could affect the quality of the final installation.

- If a Bedliner is fitted, there may be some additional trimming required.
- Recommended installation by 2 people.

1

- Clean & wiped dry top rails to prepare for the hard lid installation.



2

- Clean & wiped dry
- Add the 3mm foam tape to the front rail.
- Make sure it goes the full length to each side rail.



3

- Remove torque bolts using the T45 and remove them on both sides.
- We recommend using an impact drill.
- Remove tie hook.



- Trim the bedliner in each corner as shown,



- Install tie hook on both sides Replacing the top large washer with 4xM8 large stainless washers.



4

- Remove top bedliner cap.
- The cap can be reused on the hard lid frame to hold the top of the bedliner.



5

IMPORTANT

The front of the hard lid needs to go behind the front of the bedliner as per below picture.




- Carefully with two people lift and drop in the Hard lid,
- Drop the front end it first followed slowly by the rear.

NOTE: Having the tailgate down helps to avoid hitting it.



6


Ensure the lid is pushed as far forward as possible. Push on both rear corners to make sure both sides are hard up against the front wall of the deck.



7

- Open lid by twisting handle.
- With one person on each rear corner, lift the lid open.
- While one person holds the lid open, install the gas struts as shown.

Note:
While opening the lid hold the rails against the deck to stop them slipping off the deck rail.



8


ATTACHMENT BRACKET
The attachment bracket needs to have the 45 degree fold at the top.

M8
WASHER

M8
SPRING WASHER

M8x40mm


- The attachment brackets are assembled as shown.
- Ensure parts are fitted in correct order as shown.
- Use the hole closest to the bottom of the vehicle rail.



- The attachment brackets go in the 4 corners
- Loosely put all 4 attachment brackets in.
- Push down on the rails and tight the brackets at 1 & 2 first.
- Push down on the rails and tight the brackets at 3 & 4 last.

1 & 2



3 & 4



10



- Adjust the latch pin back or forward to have it centred in the latch.
- It is important to make sure it is centred and is not catching on the side of the latch.
- Tighten M6 nuts once it is in place.

The pin needs to not catch on these surfaces.



12

- Adjust the latch up and down till the lid latches to the customers liking.
- Ensure the lid seals well around the d-seal.



Thank you for getting

RAD

**FIND US @
RADHARDLIDS.CO.NZ**