

FITTING INSTRUCTIONS FIT1338

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

STONE GUARD MERCEDES SPRINTER

SG578B

MADE IN NEW ZEALAND

Marking the Rivnut Position

- Begin by applying masking tape to the A-pillar in the area shown.
- Measure **120mm vertically** up the A-pillar from the indicated reference point and mark a horizontal line on the tape at this height (align with the dotted line shown).
- From the edge of the windscreen, measure **25mm outward** along this dotted line.
- This point marks the location for the **bottom Rivnut**.

Repeat this process on the opposite side of the vehicle to ensure symmetry.

Stone Guard Clearance Adjustment

- After installation, the **stone guard may interfere** with the windscreen wipers or the bonnet.
- If this occurs, gently **pull along the bottom edge of the stone guard**, focusing on the area where the **two support bars** are located. This will help adjust the fit and provide necessary clearance.

