



AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

FITTING INSTRUCTIONS FIT1339

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

HEADLIGHT COVERS FUSO SHOGUN 2025+

HG831C

MADE IN NEW ZEALAND

Remove a trim piece held on with plastic clips



PULL FROM THIS GAP



Remove the two (2) 10mm bolts securing the front trim piece located above the headlight.



Once the bolts are removed, gently pull the trim piece forward to release it from the clips.



airplex

AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

Position the Headlight Cover

Slide the headlight cover underneath the headlight assembly, ensuring it aligns properly with the surrounding panels.



When installing the headlight cover, ensure that the bottom is **positioned behind the metal tab**. This is necessary for proper alignment and secure fitment.



airplex

AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

Position the top of the headlight cover behind the trim panel until it fits securely



Line up the trim panels with the truck's edges and clips.
Press firmly so the clips snap into place.
Make sure the panels sit flush and fit secure



airplex

AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

Put the trim panels back in place, lining up the clips and edges.
Press the panels firmly so the clips click in.

Put the two 10mm bolts back above the headlight and tighten them.

Check that everything fits well and is secure.

