

TB614 FITTING INSTRUCTIONS FIT1348

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

PRODUCT DATA

Trailer Safety Kit

Page 2 of 3



Installation Guide



Step 1. Place the first half of the link through the hitch point on either side of the tow bar.



Step 2. Place the other half of the link through the eye of the hook.



Step 3. Bring the two halves of the links together and partially insert locking pin to hold the parts together.



Step 4. Insert the locking collar with the recessed side facing the pin and push the pin in until it holds the collar in place.



Step 5. Using a hammer, tap the pin through the collar until it emerges on the other side of the links.



When using two chains, repeat the process on the other hitch point of the tow bar.

Disclaimer: while every reasonable effort has been made to ensure that this document is correct at the time of printing, Hobson Engineering®, its agencies and employees disclaim all liability in respect to anything or the consequences of anything done or omitted regarding the whole or any part of this document.

Bolt Tension | Anti-Vibration | Product Reliability | Traceability

hobson.com.au **QUALITY FASTENERS SINCE 1935**



20160108