



AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826
info@airplex.co.nz www.airplex.co.nz

INSTALLATION GUIDE FIT1358

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

BYD SHARK Central Lock Patch

LOOM-PB-CL01

Pinpointing the Plug Location

1. **Accessing the Cavity:** Open the front and rear passenger doors. Remove the floor scuff plates/sill trims, and gently pop loose the internal **lower plastic trim panel covering the B-pillar**.
2. **Finding the Factory Junction:** Look towards the bottom base of the B-pillar cavity. The factory central locking plug sits right where the main body wiring bundle splits off to feed the rear door's latch assembly and locking mechanisms.
3. **Plugging in the Patch Harness:** Your Lumen/aftermarket adapter will patch directly inline with this connector. From there, you route the auxiliary locking wire down into the floor channels, running it toward the rear of the cabin.



Remove the interior kick panel on the floor

airplex

AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826
info@airplex.co.nz www.airplex.co.nz

Remove the B pillar cover to access the factory plug in the pillar.





AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826
info@airplex.co.nz www.airplex.co.nz



Access the factory plug in the pillar and install the patch loom.



Find a suitable entry point for the canopy or roller lid wiring in enter the vehicle.

airplex

AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826
info@airplex.co.nz www.airplex.co.nz

Under the rear passenger seat there is a readily accessible factory grommet in the floor that permits easy access. Make sure you seal around the inside and outside of the penetration once wire has been inserted.

