

FITTING INSTRUCTIONS FIT1368

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

NUDGE BAR MITSU TRITON 2007-2015

NB103-SS &
NB103-BLACK

1. Bolt M 10 x 1.25 x 35 , 2 Pcs.
2. Spring Washer M 10 , 2 Pcs.
3. Washer M 10 , 2 Pcs.
4. Washer M 8 , 10 Pcs.
5. Bolt M 6 x 1.0 x 20 , 2 Pcs.
6. Bolt M 6 x 1.0 x 15 , 4 Pcs.
7. Nut M 6 x 1.0 , 4 Pcs.



1. Bolt M 6 x 1.0 x 15 , 4 Pcs.
2. Washer M 6 , 8 Pcs.
3. Nut M 6 x 1.0 , 4 Pcs.



airplex

AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

airplex

AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

FITTING PROCEDURE

