

FITTING INSTRUCTIONS FIT1374

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

WEATHER SHIELDS NISSAN D22

9822RH & 9822LH

1. Place Weather shield on door and adjust so that the front section seals on sponge strip and fits correctly on door.
2. Note the clips similar to those in the diagram and lower the window glass.
3. Position these clips onto the rubber window molding and fasten loosely to the Weather shield with the screws supplied.
NOTE: The clips do not fit between the rubber window moulding and door frame. They will press into the rubber, clear of the glass when finally tightened.
4. Tighten all the screws, but do not over-tighten.

INSPECTED BY:

