



C² Super Hard™ - burnished

Before beginning, always read MSDS and Product Data Sheet for complete instructions and safety information. Always prepare a test panel before proceeding.

SURFACE PREP BASED ON THE SURFACE CONDITION AND DESIRED FINISH

- If necessary, grind the surface and finish with 200 resin diamonds and for better sheen finish with 400 resin diamonds,
- Clean the surface well with water and auto scrubber.
- If grinding is not necessary, clean the surface well with auto scrubber only and remove any oil spots.
- Please refer to complete surface preparation for the C2 Super Hard on www.cretecolors.com.

C2 SUPER HARD AFTER THE SURFACE WAS PREPARED

- Shake well the C2 Super Hard or C2 Hard in the packaging container.
- Pre wet the microfiber with C2 Super Hard before application.
- Apply C2 Super Hard by spray and evenly spread with microfiber applicator in a swivel motion. Avoid over-application. Continue spray applying sufficient C2 Super Hard to maintain a wet edge with the microfiber pad. Best results are achieved when two people are used for application – one to spray the product while the other uniformly distributes the product. Refer to the Product Data Sheet for how to determine proper application rates.
- Let the surface dry for a minimum of 15-30 minutes.
- Burnish C2 Super Hard with the propane driven, high-speed burnisher and the 800 diamonds impregnated pad.

PLEASE NOTE:

- Do not over apply.
- Use ONLY neutral PH cleaner for maintenance. The best cleaner is our lithium based cleaner – C2 Maintenance
- Please refer to the complete application instruction available on the website at www.cretecolors.com

