





INSTALLATION GUIDE

- 1) Insert hardwood stakes* (or star-droppers) into ground.
- 2) Join the 2 halves of the Willunga guard together with the supplied joiners (stainless steel cable ties can also be used).
- 3) Secure the guard on both sides to the stakes with stainless cable ties.

typically 38x38mm x 1.8m hardwood stakes are used, stock code PL383818E

Willunga dimensions: 1600mm high x 700mm diameter, stock code: TGWIL1600

< The included clips can be used with Tek-screws into hardwood posts or fitted to star-droppers with supplied bolts. Alternately stainless steel cable ties are used to fix the guards together and to the post.

BEFORE INSTALLATION

Useful tools:

Spear & Jackson 3LB (1.3kg) Club Hammer, stock code GTSJFGCH3

Bighorn Post Knocker for 38mm stakes. stock code BHPKST

AFTER INSTALLATION

 $\mathsf{SOLO} \cdot \mathsf{Neutrog} \cdot \mathsf{Seasol} \cdot \mathsf{BAHCO} \cdot \mathsf{Francital} \cdot \mathsf{Pellenc} \cdot \mathsf{Wolf} \cdot \mathsf{EZE} \cdot \mathsf{LAP} \cdot \mathsf{Pottiputki} \cdot \mathsf{BIGshot} \cdot \mathsf{Fiskars} \cdot \mathsf{Arbortec} \cdot \mathsf{Permaloc} \cdot \mathsf{Samson} \cdot \mathsf{EKO} \cdot \mathsf{Harvestwear}$









P: 1300 760 642

www.arborgreen.com.au F: 1300 760 643 sales@arborgreen.com.au