

Satisfactory performance cannot be obtained from the spread bore unless the correct gasketing is used between the carburetor and intake manifold. Certain original equipment spread bore manifolds have an exhaust crossover track. This consists of two holes (approx. 3/8" diameter) beside the primary bores (smaller bores).

If your manifold has this exhaust crossover slot, prepare for the installation as follows:

1. Install the asbestos gasket supplied with the carburetor.
2. Place the stainless steel plate originally supplied with the vehicle on top of the asbestos gasket.
3. Mount the carburetor on top of the stainless steel plate with no additional gasket between the plate and the carburetor.