

## **SLIMLINE WATER TANK FITTING INSTRUCTIONS**

Tank is to be installed between the body rails and screwed to crossmembers or underside of body floor. **DO NOT USE RATTLE GUN OR DRILL TO TIGHTEN TEK SCREWS.**

Mounting brackets are attached to the tank with six (three each per side), 10mm coarse metric stainless steel screws into threaded brass inserts moulded into the tank. It may be necessary to remove these brackets to maneuver tank into position.

Filler and vent tube to be attached to front of body cross board towards outside so it is above the full level of the tank.

### **Filling Instructions**

Use snap on garden fitting where available and **food grade hoses** and attach to outlet tap, turn on tap and hose and fill back through outlet tap of filler tube.

For vehicles with raised body and spare tyre above the chassis – tank may slide in from rear, otherwise it may be necessary to remove exhaust pipe or drop the tail shaft, or raise the body.

Position tank clear of long range fuel tanks and preferably towards the front to balance vehicle, secure tank to the body using metal tek self tapping screws – at least six or eight either side.

Put Loctite, Silastic or five minute Araldite on tank screw threads to prevent them vibrating loose.