


Opal Progressive Shower System Trim Kits Only

Nero



Lead Free




Versions:202506




Drawing	Specifications	Packaging Includes
	Watermark License WM-060073 Temperature Rating Min 1°C-Max 75°C Pressure Rating Min 150kpa - Max 500kpa	1x Plate 1x Hand- Wheel 1x Diverter Knob 1x Hand Shower(Within Check- Valve) 1x 1m PVC Hose 1x Shower Bracket
	Finish & SKU Graphite NR252003ctGR Brushed Gold NR252003ctBG Brushed Bronze NR252003ctBZ Brushed Nickel NR252003ctBN	


*Dimensions are nominal measurements only.




1. Install tiles and drill holes with diameters of Ø30, Ø45, Ø45.
2. Remove the pressure test plug.
3. Assemble the cutting gauge onto the mixer body, make it flush with the tile surface, and trim off any excess part after assembly.




4. Remove the cutting gauge and protective sleeve.




5. Adjust the distance between the Diverter knob and the tile surface to 28-31 mm, as shown in the diagram.
6. Place the wall plate onto the mixer body.




7. Apply waterproofing in the gap between the ceramic tile and the water outlet.




8. Thread the water outlet adapter onto the in-wall body, and seal with Teflon tape.
9. Assemble the Backplate, washer, and shower bracket onto the main body, then secure with screws.



- Follow step 10 to install the Hand-wheel and the Diverter Knob
10. Attach the wear-resistant O-ring, hand-wheel/ Diverter knob, grub screw, and silicone cap, securing them in place.



11. Attach the shower hose and hand shower, securing them in place.



12. Installation is now complete. Test for leaks.

Nero

