

Fitting Instructions

Drip seal

LAS9001



Length:.....

Contents include

Aluminium drip guard
Flexible cover strip
Stainless steel fixing screws and plugs
Fitting instruction

Tools required

Tape measure
Pencil or marker
Saw (power or hand)
Power drill
4mm drill bit
6mm masonry drill

For further information about our products please visit our website

www.lorientgroup.com

t: +61 (02) 9905 0868
f: +61 (02) 9905 0883
e: admin@lorientau.com.au

Instructions

It is not necessary to remove the door from its hinges – however ensure the proposed position of the guard does not interfere with the operating arc of the door.

1. Remove the drip guard from the packaging and measure the door frame width.
2. Guard width should be the same as the overall frame width (if fixing directly to the frame) or add 100mm to frame width to provide a 50mm overhang on either side of the doorframe (if fixing to the wall).
3. Remove flexible cover strip. Mark the guard with a pencil to the desired length and cut through using a saw.
4. Using a power drill with a 4mm drill bit, create fixing holes in the guard at the required positions.

Please note: Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Lorient reserves the right to make alterations or delete installation detail without prior notice.

5. Position the guard centrally above the door and mark out hole centres.
6. Using a power drill with a 6mm masonry bit, create fixing holes in required position. Insert supplied fixing plugs. (Metal door jambs, if mortar filled, will require a clearance hole before drilling with a masonry bit. If unfilled, drill pilot holes and screw fix with stainless self tappers supplied).
7. Apply a bead of water resistant sealant along the back face and fix the guard in position using supplied stainless steel screws.
8. Refit the flexible cover strip to hide screw heads and trim to length.



Important: Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.

NOTE: For effective operation, the LAS9001 drip guard requires a minimum of 38mm overhang either side of the door.

Other Lorient products:

Acoustic, smoke & fire seals
Fire resistant glazing systems
Fire resistant door hardware
Air transfer grilles/ dampers
Georgia Pacific doors