

StepNpull® should be mounted approximately $\frac{1}{8}$ " from the bottom and outer edge of the door.

1. Mark the holes with a pencil while holding the StepNpull® against the door at a level mounting position.
2. Use a $\frac{5}{16}$ " bit to drill the center hole.
3. Use the sexted bolt for the middle hole.
4. Level the StepNpull
5. Use the $1 \frac{1}{4}$ " screws for the outside holes
6. Tighten sexted bolt.