

## Entrance set installation (steps 1 - 8)

**1**

- Establish height that lock will be on the door.
- Cut mortice in door as per sizes shown on template.
- Determine what lever, cylinder or turn knob holes are required.
- Drill required furniture holes from both sides of door.

Refer to instructions Lockwood Mortice Lock for door preparation and lock installation.

**2**

— Hex nuts

Entrance set  
Parts and assembly

**3**

Hole positions for lever assembly

Measure door thickness to determine the correct choice of screw length.

**4**

48mm  
32 - 38mm Door Thickness

56mm  
38 - 45mm Door Thickness

Screw lengths for door thickness.

**5**

Square hole in Mortice lock

Align spindle into square opening in Mortice Lock, position lever assembly so that it operates downwards to retract bolt.

**6**

Horizontal screw holes

Align and fit hex nuts into the exterior side of door through the horizontal screw holes.

**7**

Rotate lever to fit screws

Align screws through interior side of door. Fasten lever furniture to both sides of door with screws and hex nuts.

**8**

Position removal tab to the bottom

Removal tab

Position cover plate escutcheons firmly over the furniture. Position removal tab to the bottom.