

MNC5711 VERTICAL ROD EXIT DEVICE-RERVERSIBLE
INSTALLATION INSTRUCTIONS
LHR door shown , RHR door opposite

A MAIN CHASSIS & TOP AND BOTTOM LATCHES MOUNTING SCREWS
For steel prepared doors , drill / tap and use supplied machine screws. For thin gauge metal , non-prepared doors or for labeled wood doors use thru bolts. see template for details on mounting screws.

