



LOCKTON

Commercial Hardware

1

1. Prepare fixing holes in door and frame (use template)
2. Assemble arm to body at 22.5° to back face.
Secure arm and rail foot with bolts provided.

2

3. Fix body to door (4 screws).
Slip rail foot into track and insert end cap.

3

4. Push track and arm towards frame and secure in position (2 screws).

4

NO.1 CLOSING
NO.2 LATCHING
See instructions on rear of trim plate

5. When adjusting please note there is a **MAXIMUM OF 2 TURNS**. Over adjustment will affect the performance of the closer. In such instance our Guarantee becomes VOID.

5

6. Insert trim plate and lower spindle cover.

Regular Fixing - Pull Side

Max. Opening 180°

Max. Opening 180°

FIT ARM MECHANISM (22.5°)
Right hand 22.5° 22.5° Left hand

Transom Fixing - Push Side

Max. Opening 180°

Max. Opening 110°

FIT ARM MECHANISM (22.5°)
Right hand 22.5° 22.5° Left hand