# LOCKTON

# SG-ML95 MORTICE LOCK INSTALLATION TEMPLATE



**95 mm BACKSET**

**95 mm BACKSET**

**WARNING!**

1. ONLY DRILL THE HOLES THAT ARE REQUIRED TO SUIT THE LOCK FUNCTION.
2. ENSURE LOCK IS REMOVED BEFORE DRILLING ANY HOLES
3. DRILL EACH HOLE FROM BOTH SIDES

2 x HOLES - 20 mm DIA
FOR CYLINDER

2 x PILOT HOLES
- 2.5 mm DIA

2 x HOLES - 20 mm DIA
FOR CYLINDER

7 x HOLES - 22 mm DIA
90 mm DEEP

1 x HOLE - 22 mm DIA
FOR TURNKNOB

1 x HOLE - 22 mm DIA
FOR TURNKNOB

DRILL REQUIRED
HOLE POSITION
5 mm DIA
FOR ROUND ROSE
FURNITURE

DRILL REQUIRED
HOLE POSITION
5 mm DIA
FOR ROUND ROSE
FURNITURE

HANDLE HEIGHT

HANDLE HEIGHT

1 x HOLE - 22 mm DIA
FOR SPINDLE

1 x HOLE - 22 mm DIA
FOR SPINDLE

2 x HOLES - 7 mm DIA
FOR PLATE FURNITURE

2 x HOLES - 7 mm DIA
FOR PLATE FURNITURE

FOLD DOTTED LINE ALONG EDGE OF DOOR

FOLD DOTTED LINE ALONG EDGE OF DOOR

**ALIGN WITH BOTTOM OF FACE PLATE**

**ALIGN WITH BOTTOM OF FACE PLATE**