MAJOR MANUFACTURING INC

TO INSTALL A500 BOLT: LOCATE A500 ON DOOR EDGE. CHOOSE FOUR OF THE SIX MOUNTING HOLES PROVIDED AND MARK THE CENTER OF ONE. DRILL A 5/16" HOLE THROUGH THE DOOR AND INSTALL ONE SET OF FASTENERS. SQUARE A500 TO DOOR AND DRILL AND INSTALL BALANCE OF THE FASTENERS. DRILL A 3/4" HOLE WHERE THE LOCKING BOLT CONTACTS FRAME AND PRESS IN THIMBLE STRIKE IF REQUIRED.