



BEP SALES
 CUSTOMER CORRESPONDENCE
 NPF.
 DATE
 SIGNATURE
 PRE PACKAGE INSPECTION
 REQUIRED? SIGNED



Must be configured so Power is removed
 from aux coil, after trip has occurred.



DATE	ECO	DATE	DESCRIPTION	DRAWN	APPRVD	ECO	DATE	DESCRIPTION	DRAWN	APPRVD
27/11/14				K.MORE						
DWG No.										
TRIP COIL BREAKER										
NPF #										

TITLE:

TRIP COIL WIRING

BEP
 LEADING ELECTRICAL DESIGN
 BEP MARINE LTD.
 55 Paul Matthews Road, Albany
 Auckland 0632 N.Z.
 PH 09 415 7261 FAX 09 415 9327
 www.bepmarine.com