


Spare Parts Diagram for WORRVM



Item	Part Number	Quantity	Designation	OIN	Additional
1	7204200	1	U-tang		
3	7204404	1	BLADE LEVER RR-VM	7204404	
3A	7204011	1	Blade with tang	7204011	Incl. Ref. 1, 3, 4, 6-9, 11-15
4	7270201	3	SCREW		
6	7201203	4	PLASTIC ROLL		
7	7200201	1	ROLLER SUPPORT		
8	0018101	2	BOLT		
9	7280200	2	NUT	7280200	
11	7062503	3	AXLE CAP		
12	7211210	1	PIN		
13	0018105	1	BOLT		
14	7200211	1	Rivet		
15	7200212	1	DISTANCE BUSH D9x13,1		
16	7204012	1	Fork		
16A	1315101	1	COLLAR		
16B	7204013	1	Link (compl. mounted)	7204013	Incl. Ref. 16-19,36,37
17	7081228	1	Spring	7081228	
18	7200202	1	LOCKING BAR	7200202	
19	7200207	2	CAP	7200207	
20	0018836	2	DOWEL PIN		
21	7204410	1	Cutter lever, coated	7204410	
22	7200100	1	LEVER		
23	5702105	1	RCM CORD HANDLE		
24	7201101	1	TACKLE LINE		
25	7204201	1	TENSION SPRING		
26	0018106	1	BOLT		
27	7252202	1	bush		
28	7275201	1	SPRING PLATE		
29	7275202	1	STAR WHEEL	7275202	
30	7275200	1	SCREW		
11	7082503	3	AXLE CAP		
32	7200209	1	SPACER	7200209	
33	7200200	1	JOINT ADAPTER	7200200	
34	2728300	1	SAFETY DEVICE		
35	7231217	1	CORD	7231217	
36	7204100	1	Handle Shell, Upper		
37	7204101	1	Handle Shell, Lower		