

SUBJECT: FUEL SHUT-OFF SOLENOID

This unit is equipped with an electrical fuel shut-off solenoid.(Located on the fuel bowl under the choke pull-off)

When installing this unit in an application with no shut-off valve, remove this part from the remanufactured unit and install with the plug supplied on the original unit.