

To install the rear caliper on the vehicle

1. use an allen wrench to turn the manual adjustment gear clockwise until the brake pads touch the rotor
2. then back off one-third turn.

Note: Manual adjustment gear is located on back of caliper, inside housing. Remove bolt on back to access.