




Assembly Instructions

MARLIN FLOOR LAMP




Component Checklist

REF	A	B	C	D
PART				
NAME	Lamp Base	Lower Pole	Middle Pole	Head
QTY	1	1	1	1

Putting Me Together

WARNING: Make sure the lamp is unplugged from the wall socket lamp while changing bulbs.



- ① Screw Head (D) onto Middle Pole (C). Turn Middle Pole (C) counterclockwise to tighten securely.
- ② Screw Middle Pole (C) onto Lower Pole (B) and turn Lower Pole (B) counterclockwise to tighten securely.
- ③ Screw Lower Pole (B) onto lamp base (A) and turn lamp base (A) counterclockwise to tighten securely.
- ④ Place Lamp Base (A) on a flat surface.
- ⑤ Install a light bulb (not included) into the lamp holder, turn clockwise to tighten securely.
- ⑥ Insert the plug into your wall socket, turn on the switch and enjoy your Marlin Floor Lamp!

220-240V-50Hz B22 Max. 40W

Bulb not included