





Assembly Instructions

HESTON BAR CART



Component Checklist


REF	PART	NAME	QTY
A		Bar cart frame	1
B		Glass shelf	3
C		Bumper	18

## Putting Me Together

**NOTE:** You will need a minimum of 2 persons to assemble due to size and weight of glass shelf.




1



- Apply adhesive bumper (C) onto inner metal frame edge on each level, so as to provide a buffer for glass shelves.
- **TIP:** Apply one bumper to each corner and one to the center of longer sides of frame on each level.

2




- Gently place glass shelf (B) on to metal frame (A) fitted with bumper (C).
- **TIP:** Work from the top shelf down and support shelf from under side as you lower it carefully into frame.

# Assembly Instructions

## SAFETY ANCHOR - METAL CONSOLE

- ① Determine where the furniture is to be placed and mark the location on the wall for the mounting bracket screw near top of console leg.
- ② Drill a 9mm hole in the wall. Press the plastic anchor into the hole and gently tap until the flange on the anchor is against the wall surface.
- ③ Position the bracket over the anchor and use the longer screw to securely attach the bracket to the wall.
- ④ Place the furniture so the bracket on the wall is in line with furniture leg.
- ⑤ Lace the end of the nylon restraint strap through hole in bracket and wrap around furniture leg. Bring both ends together and slide the beaded end of the strap through the keyhole shaped slot in the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
- ⑥ To double lock, return the beaded end back through the keyhole.
- ⑦ Check to make sure the strap is securely laced and locked to the brackets.



### WARNING - Secure Furniture with Anchor Kit Provided



**NEVER put a TV on this furniture.**







**This is a permanent label. Do not remove!**

#### Children have died from furniture tipover.

This furniture type is at high risk of toppling over:

- ALWAYS secure furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

PART	NAME	QTY	PART	NAME	QTY
	Wall Plug	2		Long Screw	2
	Metal Bracket	2		Ties	2