

SUN®Rinse Aid Crystal Clear



Reduces rinse water surface tension to promote rapid spot and streak free drying of dishes, trays and utensils.

MULTI ACTION

Spotless

 Designed to reduce spotting and streaking on glassware and cutlery

Sparkles

•Works with Sun Dishwasher Powder to produce spotless sparkling results

Fast Drying

Promotes more efficient drying on dishwasher

INSTRUCTIONS FOR USE

- 1.Place Rinse Aid bottle nozzle in the rinse aid dispenser (refer to your dishwasher instruction booklet for details).
- Squeeze the bottle to fill the rinse aid dispenser to the recommended level.

FOR BEST RESULTS

- •Check the dispenser level regularly.
- ·Store out of direct sunlight.

Use Overview

Product Specifications

Parameter	Results	
Appearance	CLEAR BLUE LIQUID	
pH (1% solution)	5.0	

Available Items

Code	Description	Pack Size	Availability
5956141	SUN® Rinse Aid	12x500ml	AU & NZ

These figures are typical values and should not be interpreted as specifications.

Environmental Update

- ✓ Recyclable-Sun Rinse Aid bottle and outer carton are recyclable.
- ✓ Biodegradable -The surfactant in Sun Rinse Aid is readily biodegradable according to Australian Standard AS4351.
- √ Phosphate Free
- ✓ Septic Tanks –This product is suitable for use with septic tanks when diluted in normal use. See septic tanks manufacturing instructions for details

Approvals

✓ NZFSA Approved C32 (All animal product except dairy)

Safety Reminder:

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at www.diversey.com or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.

For additional information, please contact us at: Diversey Australia Pty Ltd Toll free: 1800 647 779, Diversey New Zealand Ltd Toll free: 0800 803 615 www.diversey.com

