

Please Read the Instructions Carefully

1. Shipment.

Carefully Unpack the Movement

2. Removing the Rear Cover.

Locate the "Open Here" Marker on the Rear Cover
Use your Thumb to Lever the Cover Off the Movement

3. Battery.

Locate the available space for the Battery
Locate the Positive + and the Negative - of the Movement
Locate the Positive + and the Negative - of the Battery
Insert the "N" Type / 1.5 Volt battery Correctly

4. Time Adjustment.

Use the Thumb Wheel to Adjust the Hands
Replace the Rear Cover when Finished.

5. Inserting the Movement

Hold the Movement Over and Above the Mounting Hole
Lean the Movement to the side and lower into the Hole
Compress 3 of the Mounting Springs to fit as you Lower
Compress the last Mounting Spring and Press Down Until Fitted.

