
Our new MVTQCP14 demonstrates the latest in chime movement technology. It uses standard American "T" shaft clock hands, and can easily be operated without a pendulum by leaving the black plastic pendulum arminists shipping position.

## (A) To Set The Time And Melody

- Carefully plug the 3" speaker into the wire connected with the movement.
- The movement is factory set at apx. 5:50 a.m. Please install your heads in that position.
- Continue with manufacturers instruction.
- 4. To set the time and melody, please make sure to turn the hand <u>CLOCKWISE</u>. If present time is P.M., make sure hour hand passes through 12 o'clock until the desired time is shown. During setting time, you keep hearing sounds, but keep continuing until the desired time is shown. Once the desired time is set, melody starts sounding correctly.
- \* The 4x4 mode will not work correctly during the first hour after time is set. However, after that, it works perfectly. This is normal condition for this movement.

## (B) Melody Function



## a) MONITOR

To demonstrate the hourly sound, select the melody by e) button and press the "MONITOR" button.

## b) VOLUME: Rotary volume

<Important>

- c) SET:
- d) RESET:

These are for technical use and please never touch after you insert the batteries.

- e) SELECT: Melody select
- 4X4 WESTMINSTER: Westminster + Striking at 00 min; 1/4, 2/4, 3/4 Westminster at 15,30 and 45 min respectively.
- 4X4 AVE MARIA: Ave Maria + Striking at 00 min, 1/4, 2/4 & 3/4 Ave Maria at 15, 30 and 45 min respectively.
- WESTMINSTER: Westminster + Striking at 00 min.
- BIM BAM: Bim Bam at 00 min (e.g. at 1 o'clock, 1 strike of Bim Bam; at 2 o'clock, 2 strikes of Bim Bam, etc.)
- f) SOUND: Sound ON/OFF select
- NIGHT OFF: Night shut off mode. Sound turn-off from 11:00 p.m. to 5:45 a.m. automatically.
- 24 Hr ON: 24 hours, sound turn-on.
- OFF: Sound off mode.