

Implementing

Insert new LR6 AA (1,5 V) Alkaline batteries according to the +/- symbols.

Remove the transport lock by pressing cautiously to the right if necessary.

Melody selection

You can choose between the traditional Westminster chime 4/4 melody quarterly played and striking the full hour and the Bim bam melody half an hour played and counting the hour.

Right after selecting the melody (WM or BB) the clock starts chiming at the next full hour. The selected melody as well as one time the hour strike is played at that first full hour. At the next full hour the strikes occur cumulated, the clock movement synchronises itself for the first time when it passes the 1 o'clock position. Afterwards the hour strike will be according to the correct time of day.

When switching the melody from Westminster to Bim Bam or conversely the requested melody occurs at the next full hour.

The melody which is currently played is not interrupted by switching the melody during a sequence.

Night reduction

Additionally there is a night reduction function during which the melody is played at a reduced volume.

While the night reduction is activated the melody occurs at a reduced volume from 22:15 o'clock to 6:45 o'clock.

In order to activate the night reduction set the melody switch to the WM or BB „moon“ position.

If the night reduction sets in during the day instead of during the night, please put the time forward by 12 hours.

If no night reduction is requested, set the melody switch to the WM or BB „sun“ position.

Volume control

Three volume levels are available (full volume, reduced volume and off). Please select by putting the knob to the corresponding position.