

INSTRUCTION

This high quality solid brass time piece is operated by a button cell battery (Type SR626 SW or compatible) under normal Conditions, the battery should operate your clock for at least 2 years.

To adjust the time: Pull out the adjusting knob and turn until the desired time is shown, push back the adjusting knob.

To Clean: Use a soft cloth, do not use any chemicals or soap.