


Closing Speed Adjustment



FAST SLOW

Power Adjustment



Use 13mm Open end wrenches

EN3	EN4	EN5	EN6
-10	+0	+10	+20

Factory presetting size: EN4

- Adjustment of clearance between hinge jamb and door stile: Loosen screws(B)and(C)
- Adjustment of door height:
Loosen screws(B),(C), and adjust screw(A).
- Centering door:
Loosen screws(B)and(C).

- Adjustment of closing speed:
 - Two regulating valves(D)and(E).
 - ⌚ Decrease closing speed.
 - ⌚ Increase closing speed.
 - Valve(D): control closing range 180°-15°
 - Valve(E): control closing range 15°-0°
- Adjustment of spring tension(F):
 - ⌚ Increase spring tension
 - ⌚ Decrease spring tension

