

LEE Decapping Die

90292



LEE DECAPPING DIE

One size fits all cases. Cases need not be cleaned nor lubed.

The decapper is retained by a collet. Should it be overstressed by an obstruction, it simply slides up without damage. To reset, loosen the decapper clamp and position the decapper flush with the clamp end and tighten. **Considerable torque force may be necessary.**

A 1/2" and 3/4" wrench are required.

Guaranteed unbreakable decapper easily removes crimped-in primers.

LEE PRECISION, INC. 4275 Highway U Hartford WI 53027
www.leeprecision.com



LD2546

6.27.12

Lee Precision, Inc.

8647

CHECKED BY