




1/2" Air Ratchet Wrench

Item No : NE-432



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List NE-432

	NO.	INDEX NO.	DESCRIPTION	Q'TY
X	01	---	Throttle Valve Plug	1
X	02	---	O-Ring	1
X	03	---	Spring	1
X	04	---	Valve Stem	1
X	05	---	O-Ring	1
X	06	---	Air Inlet Bushing	1
X	07	---	Motor Housing	1
X	08	---	Throttle Bushing	1
★	09	NE-432P09	Spring Pin	1
★	10	NE-432P10	Throttle Lever	1
▲	11	NE-432P11	Ball Bearing	1
▲	12	NE-432P12	Rear End Plate	1
★	13	NE-432P13	Rotor	1
●	14	NE-432T14	Rotor Blade (4pcs)	1set
★	15	NE-432P15	Spring Pin	1
★	16	NE-432P16	Cylinder	1
▲	17	NE-432P17	Front End Plate	1
▲	18	NE-432P18	Ball Bearing	1
★	19	NE-432P19	Exhaust Cover	1
X	20	---	Retaining Ring	1
X	21	---	Thrust Washer	1
X	22	---	Steel Ball	2
X	23	---	Spring	2
X	24	---	Ratchet Anvil	1
X	25	---	Washer	1
X	26	---	Steel Ball	1
X	27	---	Reverse Button	1
X	28	---	Spring	1
X	29	---	Spring Cap	1
X	30	---	Dowel Pin	1
X	31	---	Ratchet Pawl	1
▲	32	NE-432P32	Ratchet Yoke	1
▲	33	NE-432P33	Drive Bushing	1
★	34	NE-432P34	Crank Shaft	1
X	35	---	Needle Bearing	1
X	36	---	Ratchet Housing	1
X	37	---	Bushing	1
★	38	NE-432P38	Clamp Nut	1
X	39	---	Idler Spindle	1
X	40	---	Planet Pin	3
X	41	---	Planet Gear	3
★	42	NE-432P42	Internal Gear	1
X	43	---	Spring	1
★	44	NE-432P44	Bearing Cap	1
★	45	NE-432P45	Grip	1
★		NE-432T01	Motor Housing Assembly (06.07.08)	1set
★		NE-432T02	Throttle Valve Assembly (01.02.03.04.05)	1set
●		NE-432T03	Planet Gear Assembly (39.40.41)	1set
●		NE-432T04	Ratchet Housing Assembly (35.36.37)	1set
●		NE-432T05	Ratchet Anvil Assembly (20.21.22.23.24.25.26.27.28.29.30.31.43)	1set