




# Air Straight Grinder

Item No : QB-2925 / QB-2925L



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



## Part List QB-2925 / QB-2925L

NO.	PART NO.	DESCRIPTION	Q'TY	NO.	PART NO.	DESCRIPTION	Q'TY
★ 1	QB-2925P01	Handle C.P.	1	★ 15	QB-2925P15	Snap Ring	1
★ 1A	QB-2925P01A	Handle	1	● 16	QB-2925P16	Needle Bearing 1220	1
★ 1B	QB-2925P01B	Throttle Valve	1	★ 17	QB-2925P17	Spindle Case Nut	1
★ 1C	QB-2925P01C	Throttle Valve pin	1	★ 18	QB-2925P18	Stone Frange	1
★ 1D	QB-2925P01D	Grip	1	★ 19	QB-2925P19	Key	1
★ 1E	QB-2925P01E	Spring Pin (2*6)	1	★ 20	QB-2925T20	Collet Washer (2 pcs)	1 SET
★ 1F	QB-2925P01F	Throttle Valve Handle Spring	1	★ 21	QB-2925T21	Collet Nut (2 pcs)	1 SET
★ 1G	QB-2925P01G	Throttle Spring	1	★ 22	QB-2925P22	Wheel Guard	1
★ 1H	QB-2925P01H	Inlet Bushing	1	★ 24	QB-2925LP24	Housing Cover	1
★ 2	QB-2925LP02	Lock Nut	1	▲ 25	QB-2925LP25	O ring	1
★ 3	QB-2925P03	Rotor Case	1	★ 26	QB-2925LP26	Handle	1
▲ 4	QB-2925P04	Upper Plate	1	★ 27	QB-2925LP27	Lever	1
● 5	QB-2925P05	Ball Bushing 608	1	★ 28	QB-2925LP28	Spring Pin	1
★ 6	QB-2925P06	Cylinder C.P.	1	★ 29	QB-2925LP29	Lock key	1
▲ 6A	QB-2925P06A	Cylinder	1	★ 30	QB-2925LP30	Lock Spring	1
▲ 6B	QB-2925P06B	Cylinder Pin	1	★ 31	QB-2925LP31	Throttle Bushing	1
★ 7	QB-2925P07	Rotor	1	▲ 32	QB-2925LP32	Pin	1
● 8	QB-2925T08	Rotor Blade (4 pcs)	1 SET	▲ 33	QB-2925LP33	Throttle Valve	1
★ 9	QB-2925P09	Top Plate Washer	1	▲ 34	QB-2925LP34	T.V.cover Packing	1
★ 10	QB-2925P10	Lock Screw	1	▲ 35	QB-2925LP35	Throttle Valve Spring	1
▲ 11	QB-2925P11	Lower Plate	1	★ 36	QB-2925LP36	Throttle Valve Cover	1
● 12	QB-2925P12	Ball Bearing 629	1	★ 37	QB-2925LP37	Spring Pin	1
★ 13	QB-2925P13	Stone Spindle	1	★ 38	QB-2925LP38	Inlet Bushing	1
● 14	QB-2925P14	Ball Bearing 6002	1				