




Air Sander

Item No : QB-54 QB-55 QB-56

● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List

Item No : QB-54 QB-55 QB-56



	NO.	INDEX NO.	DESCRIPTION	Q'TY
★	1	QB-54P01	Valve Lever	1
★	2	QB-54P02	Spring Pin	1
★	3	QB-54P03	Housing Cap	1
★	4	QB-54P04	Housing	1
●	5	QB-54P05	Bearing	1
★	6	QB-54P06	Spring Pin	1
▲	7	QB-54P07	Rear Plate	1
★	8	QB-54P08	Cylinder	1
★	9	QB-54P09	O-Ring	1
●	10	QB-54T10	Rotor Blade (5pcs)	1 set
▲	11	QB-54P11	Rotor	1
▲	12	QB-54P12	Front Plate	1
●	13	QB-54P13	Bearing	1
▲	14	QB-54P14	O-Ring	1
★	15	QB-54P15	Nut	1
★	16	QB-54P16	Snap Ring	1
★	17	QB-54P17	Rotor Key	1
★	18	QB-54P18	Motor Shaft Balancer	1
●	19	QB-54T19	Bearing +Pad Retainer Set	1 set
★	20	QB-55P20	Sleeve (For QB-55)	1

	NO.	INDEX NO.	DESCRIPTION	Q'TY
★	20C	QB-54P20C	Sleeve (For QB-54)	1
★	20S	QB-56P20S	Sleeve (For QB-56)	1
●	21A	QB-55P21A	5"Pad	1
●	21B	QB-55P21B	6"Pad	1
●	21C	QB-54P21C	5"Pad (For QB-54&QB-56)	1
●	21D	QB-54P21D	6"Pad (For QB-54&QB-56)	1
★	22	QB-54P22	Regulator Lever Set	1
★	23	QB-54P23	Snap Ring	1
★	24	QB-54P24	Valve Tappet	1
▲	25	QB-54P25	Washer	1
★	26	QB-54P26	Adjust Shaft	1
★	27	QB-54P27	Compression Spring	1
★	28	QB-54P28	Adapter	1
★	29	QB-55P29	Silencer	1
★	29C	QB-54P29C	Couplings (For QB-54)	1
★	29S	QB-56P29S	Couplings (For QB-56)	1
★	30S	QB-56P30S	Air Hose	1
★	31S	QB-56P31S	Vacuum Storage Bag	1
★	32	QB-54P32	Wrench	1