


PARTS LIST

NSG-180XC

504833



PARTS LIST

(1/2)

MODEL : **NSG-180XC**

504833

ITEM	PART NO.	PART NAME	Q' ty
1	15007730	INLET BUSHING	1
2	15007640	THROTTLE SPRING	1
3	15007770	THROTTLE VALVE	1
4	15007660	PUSH SPRING	1
5	15005990	GRIP	1
6	15012010	HANDLE	1
7	Not available separately. Available only as ROTOR CASE AS (P/No.15015785)	ROTOR CASE	1
8	15003450	PLATE NUT	1
9	15012070	TOP PLATE	1
10	15012060	CYLINDER	1
11	15012100	ROTOR	1
12	15016111	VANE	4
13	15012090	BOTTOM PLATE	1
14	15005250	ROTOR WASHER	1
15	15015774	ROTOR GEAR	1
16	15015775	SPINDLE GEAR	1
17	15012140	STONE SPINDLE	1
18	15008040	STOPPER RING	1
19	15008010	SPINDLE NUT	1
20	15012040	PAPER FLANGE	1
21	15012030	PAPER PAD	1
22	15012020	PAPER NUT	1
23	15008090	LOCK SCREW	1
24	15006290	SOCKET	1
28	15006040	HOLDER	1
29		NAME PLATE	1
100	28100501	HEX. SOCKET PLUG	1
101	28201072	BALL BEARING	2
102	28201069	BALL BEARING	1
103	28201091	BALL BEARING	1
104	28206062	PIN	1
105	28207052	ROLLER PIN	1
106	28208056	SPRING PIN	2
107	28209010	KEY	1
108	28209016	KEY	2
109	28302013	OIL SEAL	1
110	61200060	O RING	1
201	24999128	TURNING SPANNER	1
202	24999132	FLANGE SPANNER	1
203	25004060	SPANNER	1

PARTS LIST

(2/2)

MODEL : **NSG-180XC**

504833

ITEM	PART NO.	PART NAME	Q' ty
	Contents of CP		
	15015420	HANDLE CP	
		1, 2, 3, 4, 5, 6, 104, 105	
	15015670	BOTTOM PLATE WBR	
		13, 101	
	15015684	TOP PLATE WBR	
		9, 101	
	15015785	ROTOR CASE AS	
		7, 24, 100	