

Part NO.	SNIT Model NO.	Quantity	Description
A	A1 L06080	1	Rubber pad
	L03010073	1	Non-standard screw nut
	A2 L0180124	1	Saddle
	ZB0006	1	Lifting arm assy
	L07216	2	Connecting rod(left)
	L07217	2	Connecting rod(right)
	L0180027	2	Connecting rod axel
	L03020013	2	Nylon locking screw nut
	L05100014	2	Clamp
B	L06043	2	Front Wheel
	L0180024	2	Front wheel sleeve
	L03030007	2	Spacer
	L05100009	2	Clamp
C	ZD0010	1	Oil Cylinder
	L03030015	4	Spring gasket
	L03010068	4	Outer hexagonal screw
D	L06042	2	Rear Wheel
	L03020015	2	Nylon locking screw nut
E	L0180188	1	Handle socket
	L03030016	2	Spring gasket
	L0180047	2	Handle socket screw axel
	L0180032	1	Handle socket wheel1
	L0180031	1	Handle socket bearing1
	L05100005	4	Clamp
	L03010066	1	Outer hexagonal screw
F	CWS001	1	Handle Assy
G	L06098	1	Spare parts tray
H	L0180026	1	Lifting shaft
	L05100012	2	Clamp
I	L05020033	2	Drag spring

