






Cylinder			
Assy No.	Part No.	Description	Qty
J3A	J301	Base+outer sleeve assy	1set
	J302		
	J303		
	J304		
	J305		
	J321		
	J323		
	J324		
J3B	J306	inner sleeve assy	1set
	J307		
	J308		
	J309		
	J310		
/	J316	locking ring	1pc
J3C	J311	inner sleeve assy	1set
	J312		
	J313		
	J314		
	J315		
J3D	J318	Piston assy	1set
	J319		
	J320		
/	J317	saddle	1pc
J3E	J301/J302/J304/J305/J306/J307/J309/J310/J311/J312/J314/J315/J318/J319/J320	seal kits	1set



Pump					
Part No.	Description	Qty	Part No.	Description	Qty
Q20	steel ball	3pcs	Q56	spring	1pc
Q21	spring	2pcs	Q59	spring	1pc
Q22	screw	2pcs	Q60	o ring	1pc
Q23	steel ball	1pc	Q61	piston	1pc
Q24	screw	4pcs	Q62	tie in	1pc
Q25	slinger	1pc	Q63	check valve	1pc
Q26	clamp	1pc	Q64	screw	3pcs
Q28	spring	1pc	Q65	locking ring	1pc
Q30	o ring	1pc	Q66	o ring	1pc
Q31	locking ring	1pc	Q68	locking ring	2pcs
Q32	o ring	1pc	Q69	o ring	2pcs
Q33	guide sleeve	1pc	Q72	spring	1pc
Q34	B3 seal	1pc	Q73	screw nut	1pc
Q35	locking ring	1pc	Q75	oil drain valve	1pc
Q36	oil pump	1pc	Q76	spring	1pc
Q37	air cylinder	1pc	Q77	clamp	1pc
Q38	spring	1pc	Q78	tie in	1pc
Q39	plunger rod	1pc	Q79	o ring	1pc
Q41	o ring	1pc	Q80	oil drain cover	1pc
Q42	piston	1pc	Q81	o ring	2pcs
Q43	OA seal	2pcs	Q82	oil drain piston	1pc
Q44	Z8 seal	1pc	Q83	oil drain bolt	1pc
Q45	piston	1pc	Q84	tie in	1pc
Q46	rubber cap	1pc	Q85	filter	1pc
Q47	tie in	2pcs	QP001	check valve assy	1set
Q49	rubber ball	2pcs	QP002	oil pump assy	1set
Q50	air inlet valve	1pc	QP003	air inlet valve assy	1set
Q52	screw	4pcs	QP004	oil drain valve assy	1set
Q53	safety valve	1pc			



Main		
Part No.	Description	Qty
Q001	oil cylinder	1pc
Q002	pump assy	1pc
Q003	tie in	4pcs
Q004	lifting handle sets	1set
Q005	housing	1pc
Q007	switch assy	1set
Q008	handle grip	2pcs
Q009	handle assy	1set
Q010	adaptor	1set
Q011	tie in	2pcs
Q012	protection cover	1pc
Q013	handle shaft	1pc
Q014	wheel sets	2sets
Q015	oil hose	1pc
Q016	screw	3pcs
Q017	screw	4pcs
Q018	screw	2pcs
Q019	screw	2pcs