

KEY SAFE






BURG-WÄCHTER KG

Altenhofer Weg 15 58300 Wetter Germany

BA Key Safe 50 mlo/kar 01/2019





en Key Safe – Operation

Dear customer.

Thank you very much for deciding for a KEY SAFE manufactured by BURG-WÄCHTER. The KEY SAFE permits a reliable storage of keys and /or other valuables.

Important: Please read the entire User Manual before you start to mount the device and before resetting.

Let us wish you a high level of security and quality of living with your KEY SAFE

Your BURG-WÄCHTER KG

To Open

Slide shutter door down to reveal the dials and the door release button. Rotate all 4 dials to the pre-set combination, grasp the sides on the top section of the box and pull lid towards you.

Resetting Combination

- 1. Open the KEY SAFE using the secret number (the factory preset is "0 - 0 - 0 - 0").
- 2. Slide the reset pin to the left and down as per arrow (Fig 2).
- 3. Rotate the 4 dials on the front to your new secret combination. Ensure the numbers are positioned centrally and have clicked into position.

Attention: If the code gets lost the opening of the KEY SAFE is impossible.

- 4. Return the reset pin to the original position.
- 5. Close the lid and check the operation of the box using the new combination.

To lock

The combination must be scrambled by rotating the 4 digit rolls.

Maintenance:

It is recommended the digit rolls are rotated weekly to keep them moving freely.

Errors and changes reserved.