




LOCKTON
ESSENTIALS

SGDC-600 - SCREEN DOOR DOOR CLOSER

I-6600 FITTING INSTRUCTIONS


Jamb Bracket

Fasten the Jamb Bracket 12-25mm from the inside of the door face on the hinge side and 25mm down from the top of the door jamb, with the 25mm self tapping screws, as shown.




Closer Setting

Connect the Rod to the Jamb Bracket using the Split Pin. DON'T deform the Split Pin. Tension by pulling the unit until flush with the pinch in the Rod, as shown. Press the Hold-Open Catch to lock the Rod in place.




Door Bracket
Insert the Door Bracket onto the Door Closer's foot. Close & latch the door. Swing the Closer onto the door & level. If the Door Bracket is facing away from the door, rotate the End Cap & Door Bracket 180° **anti-clockwise** until flush with the door.



Door Bracket

In the centre of Screw Slot A, fix the Bracket with a 19mm screw. Remove the Split Pin & closer & fasten the other 19mm screw into Slot B. Refit the Closer and Split Pin. Spread apart the Split Pin.



Closing Speed

Open the door to unlatch the Hold-Open Catch. Test the door closing speed. Use a philips Screwdriver on the Valve Screw to adjust the door closing speed.

