SMART

REMOTE ORDERING OPTIONS



COMPATIBLE WITH







SMART2S

SMART4S

SMART4B

RECEIVER COMPATIBILITY

• Suits Models: Smart Lifter, Smart roller Disc, Smart Lifter NANO & Smart roller NANO

Remote Programming Steps

Programming New Remote

- 1. Press & hold the 'Code' button until the LED displays (.) dot.
- 2. Press any button on the new remote. LED dot will switch off.
- **3.** Press the same button again. The LED dot will flash & confirm the new remote has been programmed.

Delete Single Remote

4. Hold the 'Code' button on the reciever board (garage door opener) for approximatly 8-10 seconds (until LED dot switches off.

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.