



REMOTE ORDERING OPTIONS

Art ID: **PFOB2** 



SPECIFICATIONS
Elsema
Frequency - 433.1-434.7MHz
Buttons - 2
Battery - CR2032

Art ID: **M-BT** 



SPECIFICATIONS
JMA
Cloning remote
Buttons - 4
Battery - CR2032

See **page 30-32**

Art ID: **M-LT** 



SPECIFICATIONS
JMA
Cloning remote (FIXED CODE)
Buttons - 4
Battery - CR2032

See **page 30-32**

COMPATIBLE WITH



RECEIVER COMPATIBILITY

- Suits Models:
Suits Elsema Receivers with PentaFOB
Compatibility

Remote Programming Steps

Program Remote to Receiver

1. Check that all the switches are 'OFF' on the 12 way dip-switch inside the new remote.
2. Press & hold the 'Program' button on the receiver (garage door motor).
3. Press the remote button you want to use for 2 seconds, receiver LED will flash and turn Green.
4. Release the buttons on the receiver (garage door motor) and the remote.

Program Existing Remote to New Remote

1. Open the case of an existing and functioning remote and press the 'Program' button once.
2. On the new remote, press and hold the remote button you want to use for 2 seconds.