

Setting the latch Backset







NOTE: Check the backset of the existing door hole by measuring from the edge of the door to the centre of the hole.

The ELEV64 latch can be set to either a ***60mm*** or ***70mm*** backset.

1. Lift the S1 lever as shown in the drawing & **Hold** in this position.




2. While holding the S1 Lever - **Push** down the backset switch, indicated in yellow in the drawing.



3. Adjust the latch to the required backset:

60mm: **Push** the back of the latch towards the faceplate.



70mm: **Pull** the back of the latch away from the faceplate.

