



REMOTE ORDERING OPTIONS

Art ID:
BHT3-R



SPECIFICATIONS
BOSS
Frequency - 433Mhz
Buttons - 3
Battery - LR27A


Art ID:
M-BT



See **page 30-32**

SPECIFICATIONS
JMA
Cloning remote
Buttons - 4
Battery - CR2032

Art ID:
M-LT



See **page 30-32**

SPECIFICATIONS
JMA
Cloning remote (FIXED CODE)
Buttons - 4
Battery - CR2032

COMPATIBLE WITH



HT3

RECEIVER COMPATIBILITY

- Suits Models:
BOL5, BOL6, BRD9, OL4, OL6C, BOL4, RD11 Motors

Remote Programming Steps

Adding Remote Controls - Roller Door

1. Locate the receiver board (garage door motor) behind the face plate.
2. Press the 'Learning' button once (under the large aqua button). A Yellow LED will turn on.
3. Press any button on the new remote once and hold until the Green LED blinks twice.
4. Press 'Learning' button again and the Yellow LED will turn off.

Adding Remote Controls - Overhead/Tilt Doors

1. With a pointed object push the 'Radio Set Button' on the receiver (garage door motor).
2. A courtesy light will turn on for 30 seconds.
3. Within 30 seconds push any button on your new remote until the courtesy light flashes twice.

Deleting Remote Controls - Roller Door

1. Turn off the receiver (garage door motor).
2. Press & hold the 'Learning' button and then turn the power on. Continue holding the 'Learning' button until you see 3 lights flashing.

Deleting Remote Controls - Overhead/Tilt Doors

1. Hold the 'Radio Set Button' on the receiver (garage door motor) for 5 seconds.
2. Courtesy light will then flash 7 times.